Light barrier amplifier

IMX-A2033...



Features

- · Multichannel amplifier with modulated infrared light
- 2-channel installation system for tight assembly without cross talk
- Range up to 40 m (131 ft)
- Automatic Level Control (ALC) according to assembly distance and direction
- High immunity to ambient light and interference from other light barriers
- Test function to check installation and signal strength
- Adjustment assistance for easy adjustment of the sensor heads
- Switch-on and switch-off delay
- Switching mode light/dark switchable
- Four basic transmit levels
- One transistor output (NPN/PNP) for each channel
- Transmitter and receiver connections are short-circuit proof
- 11-pin DIN railmounting socket for simple installation

Ordering Table

Supply voltage	Order code
230 V AC	IMX-A2033/230VAC
115 V AC	IMX-A2033/115VAC
24 V AC	IMX-A2033/24VAC
24 V DC	IMX-A2033/24VDC
Accessories	Order code
11-pin DIN mounting socket	ISO1
Protective enclosure	PanBox 1x2
Retaining clip	RTC11

Safety Instructions



The infrared light barriers IMX-A2033... are not safety systems and should not be used as such systems. The devices are not to be used for applications, where personal safety is dependent on their function.

Short Description

The 2-channel automatic multiplexer is an processor controlled amplifier with an integrated analysis unit. Up to two transmitters and receivers can be connected to each unit without possibility of cross talk. The automatic gain setting and the adjustment assistance enables the user to simplify the installation and work.

The amplifier has for each channel one transistor output (NPN/PNP) and a yellow status LED.

All channels can be switched independently from each other to the different working conditions. To make fine adjustments to the sensitivity of the amplifier based on the range and contamination level of the application, the user may switch to different transmit levels using DIP switches.

A control unit, which can be activated by simply pressing a button, is used to determine malfunctions in the transmitter or the receiver.

If nothing is defective, the test function shows the signal quality by flashing an LED from 1 to 10 times. The flashes are proportional to the received signal.

Infrared transmitters and receivers in different, compact and robust designs are described in the sensor heads datasheet.



Device Overview





DIP-switch setting

DIP-switch		1	2	3			4	5	6	
ON 1 2 3 4 5 6	basic tr ch	ansmit annel 1	level	switch moo chanr	ning de nel 1	basic tr ch	ansmit annel 2	: level 2	switch moo chann	ning de iel 2
	high2	ON	ON	واصعاد		high2	ON	ON	مامعاد	
	high1	ON	OFF	uark	UN	high1	ON	OFF	uark	UN
	low2	OFF	ON	light		low2	OFF	ON	liabt	
	low1	OFF	OFF	light	OFF	low1	OFF	OFF	ligni	OFF

Factory setting is marked in dark grey

Switching logic

	Ou	Outp	put status		
Beam status	mode	Indicator	Transistor output		
	light	light ≥⊗≤ 0 V	0 V		
	dark	\otimes	24 V DC		
	light	\otimes	24 V DC		
	dark	≥⊗∈	0 V		



Technical Data (at 20 °C / 68 °F)

Supply voltageAC	230/115/24 V AC	/ ±10%		Relay output
Supply voltageDC	24 V DC / ± 10%			
Power consumption (max.)	AC: 5,1 VA	DC: 2,6 W		Transistor output
Power loss (max.)	AC: n. a.	DC: 2,6 W		Switching data (max.)
(EN 61439)				Reaction time T _{ON} / T _{OFF}
max. Range (through beam) Receiver	Receiver	Receiver	Alarm output	
	IRL	IR, IRH		
Transmitter IT, ITL	7 m (ft)	13 m (ft)		Test input
Transmitter ITHP, ITH	9 m (ft)	20 m (66 ft)		
Transmitter ITA	15 m (ft)	40 m (131 ft)		MTBF (EN/IEC 61709)
				Operating temperature
Operating basis	modulated IR-light			Storage temperature
Transmit frequency	4,0 kHz			Housing material
System power	automatic			Housing protection
Switching behavior	light / dark			Mounting
Basic transmit level	Low 1 / Low 2 / Hig	gh 1 / High 2		Mounting orientation
Switching delay	0 10 s			Dimensions
Multiplex speed	4 ms			
Multiplex speed	4 ms			

Connection Diagram

Before connecting the amplifier, look on the type plate and check if the power supply is the same as the connection value. Other values can impair the unit functions or destroy the amplifier.

Caution! The AC-supply devices are isolated from main. A grounded connection on the low voltage side is required (PIN 7).



Dimensions (in mm)



